

COMPLIANCE AND DISTENSIBILITY COEFFICIENTS

<p>What is it?</p>	<p>Compliance and Distensibility coefficients are parameters of local arterial elasticity. Compliance of an arterial segment is the change in arterial blood volume due to a change in arterial blood pressure. Distensibility is compliance normalized for the starting volume.</p> <p>If the arterial segment is tethered and the flow is pulsatile, volume changes are mainly related to changes in vessel diameter; then compliance (and distensibility) can be estimated as a change in diameter or cross-sectional area for a given change in pulse pressure.</p> <p>In particular, CC, cross-sectional Compliance coefficient, is defined as the “absolute [area] change for a [pressure increment] at fixed vessel length”:</p> $CC = \text{change in area} / \text{change in pressure}$ <p>where ‘area’ can be calculated from the diameter of a blood vessel based on the assumption of circularity (i.e. $\text{area} = \pi \times (\text{diameter}/2)^2$;</p> <p>and</p> <p>DC, cross-sectional Distensibility coefficients, is defined as: the “relative [area] change for a pressure increment; the inverse of elastic modulus”</p> $DC = \text{change in area} / (\text{change in pressure} \times \text{minimum area})$ <p>where ‘area’ can be calculated from the diameter of a blood vessel based on the assumption of circularity (i.e. $\text{area} = \pi \times (\text{diameter}/2)^2$.</p> <p>Compliance and distensibility are expressions of arterial elasticity, the inverse of arterial stiffness. DC can be expressed as a local carotid Pulse Wave Velocity, in [m/s], by using the Bramwell-Hill equation. This formula gives:</p> $cPWV = 1 / \sqrt{\rho \times DC}$ <p>where ρ is the blood density.</p> <p>DC and CC express the elasticity of the artery as a whole, and more specifically Distensibility expresses the intrinsic elasticity of the artery as a hollow structure. The elastic properties of the arterial wall material can be estimated by other parameters (eg Young’s incremental elastic modulus taking into account the thickness of the arterial wall).</p>
<p>Why do we measure it?</p>	<p>DC and CC provides a local and direct assessment of arterial elasticity, a parameter that is altered by vascular ageing.</p>

<p>How can it be measured?</p>	<p>DC and CC can be non-invasively measured by local pulse pressure acquisition and instantaneous diameter measurement. Local pulse pressure of superficial arteries can be estimated by tonometry. Instantaneous diameter can be measured by image processing (e.g. Ultrasound, MRI). Units of measurement are:</p> <p>CC = $m^2 \cdot kPa^{-1}$</p> <p>DC = kPa^{-1}</p>
<p>Where is it measured?</p>	<p>DC and CC can be measured non-invasively at different arterial sites, theoretically all those that can be imaged; generally, local elasticity is assessed at superficial sites such as abdominal aorta, carotid and femoral arteries when adopting ultrasound, and other tracts of aorta when using MRI.</p> <p>Reference values for carotid and femoral elasticity are available.</p>
<p>Figure</p>	<p style="text-align: center;">Artery as a hollow structure</p> <div style="text-align: center;"> <p>The diagram shows a cross-section of an artery as a hollow cylinder. Inside the cylinder, there are four arrows pointing outwards (up, down, left, right) labeled 'Pressure'. Below the cylinder, there is a curved double-headed arrow labeled 'Distensibility'.</p> </div> <div style="text-align: right;"> <p>The graph shows two waveforms over time. The top waveform is labeled 'Pressure (mmHg)' and ranges from 0 to 150. The bottom waveform is labeled 'Diameter (mm)' and ranges from 7.1 to 7.3. Below the graph is a small ultrasound image of an artery.</p> </div> <p>Figure inspired by:</p> <ul style="list-style-type: none"> - <i>First Author:</i> Laurent S - <i>Title</i> Expert consensus document on arterial stiffness: methodological issues and clinical applications. - <i>In:</i> Eur Heart J. 2006 Nov;27(21):2588-605. doi: 10.1093/eurheartj/ehl254. - <i>DOI or link to publication:</i> doi: 10.1093/eurheartj/ehl254 - <i>Figure number:</i> 2 <p><i>Pressure's logo by Flaticon.com</i></p>

References	<ol style="list-style-type: none">1. Tozzi et al., 2000: 10.1152/ajpheart.2000.278.4.H14072. M. O'Rourke, W.W. Nichols, C. Vlachopoulos, 2012: McDonald's Blood Flow in Arteries, Theoretical, Experimental and Clinical Principles3. M. O'Rourke et al., 2002: 10.1016/s0895-7061(01)02319-64. S. Laurent et al., 2006: 10.1093/eurheartj/ehl2545. T.T. van Sloten et al., 2013:10.1016/j.jacc.2013.12.0416. L. Engelen, et al., 2015: 10.1097/HJH.00000000000006547. J. Bossuyt, et al., 2015: 10.1097/HJH.0000000000000655
-------------------	---

FEEDBACK AND SUGGESTIONS FOR THESE DEFINITIONS* CAN BE SUBMITTED AT
<https://vascagenet.eu/feedback-for-official-glossary-of-key-terms>

* These definitions have been downloaded from <https://vascagenet.eu/official-glossary> and were released on 22nd October, 2021.